



DOOSAN

Mynx 5400

SAFETY INSTRUCTIONS

- 1. Read the safety instructions carefully before operating the machine.
- 2. Do not touch the moving parts of the machine.
- 3. Do not touch the hot parts of the machine.
- 4. Do not touch the electrical parts of the machine.
- 5. Do not touch the hydraulic parts of the machine.
- 6. Do not touch the pneumatic parts of the machine.
- 7. Do not touch the coolant parts of the machine.
- 8. Do not touch the chip conveyor parts of the machine.
- 9. Do not touch the chip collector parts of the machine.
- 10. Do not touch the chip disposal parts of the machine.